

Cleaning & Care Guidelines


To keep your Snack in the Box working and looking shiny and new please follow these simple cleaning guidelines.

Daily cleaning, or after each use:

| 1. Remove | 2. dishwasher top | 3. Let dry completely |
|-----------|--|-----------------------|
| lid. | rack only, or hand wash in warm soapy water. | |
| | | |

Deep Cleaning:

Some foods, or sugary snacks may require a deeper cleaning. This is best done by removing the doors, see diagram below, then follow the cleaning instructions.



Not for use with sterilizers.

For more information please visit drinkinthebox.com, E talktous@precidio.com, T 905-412-0156